


AUTOMATIC TRANSAXLE ASSY (U441E)

40020-01

OVERHAUL


1. REMOVE SPEEDOMETER (ATM) SENSOR

2. REMOVE SPEEDOMETER DRIVEN (ATM) GEAR SUB-ASSY




3. REMOVE TRANSMISSION CONTROL SHAFT LEVER

- (a) Remove the nut, washer and control lever.




4. REMOVE NEUTRAL START SWITCH ASSY

- (a) Using a screwdriver, unstick the lock washer.




- (b) Remove the 2 bolts, and pull out the neutral start switch.




5. REMOVE TRANSMISSION REVOLUTION SENSOR

- (a) Remove the bolt and transaxle revolution sensor.



6. REMOVE BREATHER PLUG HOSE

- (a) Remove the clip and breather plug hose.




7. REMOVE OIL COOLER TUBE UNION

- (a) Remove the 2 unions.
- (b) Remove the 2 O-rings from the unions.


8. FIX AUTOMATIC TRANSAXLE ASSY

- (a) Place transaxle on wooden blocks.




9. REMOVE AUTOMATIC TRANSAXLE OIL PAN SUB-ASSY

- (a) Remove the 18 bolts.
- (b) Remove the oil pan and gasket.
- (c) Remove the gasket and drain plug from the oil pan.




10. REMOVE VALVE BODY OIL STRAINER ASSY

- (a) Remove the 3 bolts and oil strainer.




- (b) Remove the gasket from the oil strainer.




11. REMOVE TRANSMISSION VALVE BODY ASSY


- (a) Remove the bolt and ATF temperature sensor with clamp.
 (b) Disconnect the 5 connectors.




- (c) Support the valve body assembly and remove the 14 bolts.




- (d) Disconnect the manual valve control rod from the manual valve lever, then remove the valve body assembly.

**12. REMOVE TRANSMISSION WIRE**


- (a) Remove the bolt.
- (b) Remove the transaxle wire from the transaxle case.
- (c) Remove the O-ring from the transaxle wire.

**13. REMOVE GOVERNOR APPLY GASKET NO.1**

- (a) Using a screwdriver, remove the governor apply gasket No. 1 from the transaxle case.

**14. REMOVE CHECK BALL BODY**


- (a) Remove the check valve and spring.

**15. REMOVE C-2 ACCUMULATOR PISTON**

- (a) Apply compressed air (392 kPa, 4.0 kgf/cm², 57 psi) to the oil hole and remove the C₂ accumulator piston and spring.


NOTICE:

- **Blowing off the air may cause the piston's jump-out. When removing the piston, hold it with your hand using a waste cloth.**
- **Take care not to splash ATF when air-blowing.**



16. REMOVE C-2 ACCUMULATOR SPRING SUB-ASSY

- (a) Using a screwdriver, remove the snap ring and remove the C₂ accumulator spring.




17. REMOVE C-1 ACCUMULATOR PISTON

- (a) Apply compressed air (392 kPa, 4.0 kgf/cm², 57 psi) to the oil hole and remove the C₁ accumulator piston and spring.


NOTICE:

- **Blowing off the air may cause the piston's jump-out. When removing the piston, hold it with your hand using a waste cloth.**
- **Take care not to splash ATF when air-blowing.**



18. REMOVE C-1 ACCUMULATOR SPRING SUB-ASSY

- (a) Using a screwdriver, remove the snap ring and remove the C₁ accumulator spring.



19. REMOVE PISTON B-1 ACCUMULATOR


- (a) Apply compressed air (392 kPa, 4.0 kgf/cm², 57 psi) to the oil hole and remove the B₁ accumulator piston and spring.


NOTICE:

- **Blowing off the air may cause the piston's jump-up. When removing the piston, hold it with your hand using a waste cloth.**
- **Take care not to splash ATF when air-blowing.**


20. REMOVE B-1 ACCUMULATOR PISTON COMPRESSION SPRING

- (a) Using a screwdriver, remove the B₁ accumulator piston compression spring.



**21. REMOVE TRANSAXLE HOUSING NO.2 PLUG**


- (a) Remove the transaxle housing No. 2 plug from the transaxle case.
- (b) Using a screwdriver, remove the O-ring from the transaxle housing No. 2 plug.

**22. REMOVE TRANSAXLE HOUSING**


- (a) Remove the 16 bolts.
- (b) Tap on the circumference of the transaxle housing with a plastic hammer to remove the transaxle housing from the transaxle case.

NOTICE:


Differential gear assembly may be accidentally removed when the transaxle housing is removed.

**23. REMOVE TRANSAXLE HOUSING OIL SEPARATOR**



- (a) Remove the 3 bolts and oil separator from the transaxle housing.

**24. REMOVE TRANSAXLE APPLY TUBE CLAMP NO.1**


- (a) Remove the bolt and transaxle apply tube clamp No. 1 from the transaxle housing.

**25. REMOVE TRANSMISSION LUBE APPLY TUBE**

- (a) Remove the transmission lube apply tube from the transaxle housing.

**26. REMOVE DIFFERENTIAL GEAR LUBE APPLY TUBE****27. REMOVE TRANSAXLE HOUSING OIL SEAL**


- (a) Using a screwdriver and a hammer, remove the transaxle housing oil seal.

**28. REMOVE TRANSAXLE CASE OIL SEAL**


- (a) Using a screwdriver and hammer, remove the oil seal.

29. REMOVE BREATHER PLUG NO.1 (ATM)


- (a) Remove the breather plug No. 1 from the transaxle case.
 (b) Using a screwdriver, remove the O-ring from the breather plug No. 1.

**30. INSPECT INPUT SHAFT ENDPLAY**


- (a) Using a dial indicator, measure the input shaft end play.
End play: 0.3 – 0.9 mm (0.012 – 0.035 in.)

**31. REMOVE OIL PUMP ASSEMBLY**


- (a) Remove the 6 bolts and oil pump assy.

**32. REMOVE INPUT SHAFT ASSY**


- (a) Remove the input shaft assy from the transaxle case.

**33. REMOVE STATOR SHAFT THRUST NEEDLE ROLLER BEARING**




- (a) Remove the thrust needle roller bearing from the input shaft assy.

**34. REMOVE PLANETARY GEAR FRONT THRUST NEEDLE ROLLER BEARING**


- (a) Remove the thrust needle roller bearing and thrust bearing race from the direct clutch hub.

**35. REMOVE DIRECT CLUTCH HUB**


- (a) Remove the direct clutch hub from the transaxle case.

**36. REMOVE DIFFERENTIAL GEAR ASSEMBLY****37. REMOVE GOVERNOR APPLY GASKET NO.2****38. REMOVE TRANSMISSION CASE PLATE NO.1**


- (a) Remove the bolt and No. 1 transaxle case plate from the transaxle case.

**39. REMOVE TRANSAXLE REAR COVER ASSY**


- (a) Remove the 9 bolts.
 (b) Tap on the circumference of the transaxle rear cover with a plastic hammer to remove the transaxle rear cover from the transaxle case.

**40. REMOVE FRONT CLUTCH DRUM THRUST NEEDLE ROLLER BEARING**


- (a) Using a magnetic finger, remove the thrust needle roller bearing.

**41. REMOVE TRANSAXLE CASE 2ND BRAKE GASKET**


- (a) Using a screwdriver, remove the 4 gaskets.

**42. REMOVE INTERMEDIATE SHAFT ASSY**

- (a) Remove the intermediate shaft assy from the transaxle case.

**43. REMOVE 2ND COAST & OVERDRIVE BRAKE DISC**


- (a) Remove the flange, 2 discs and 2 plates from the transaxle case.

**44. INSPECT 2ND COAST & OVERDRIVE BRAKE DISC**


- (a) Check to see if the sliding surface of the disc, plate and flange are worn or burnt.
If necessary, replace them.

NOTICE:


If the lining of the disc is peeling off or discolored, or even if a part of the printed mark is defaced, replace all discs.

**45. REMOVE 2ND COAST & OVERDRIVE BRAKE FLANGE HOLE SNAP RING**


- (a) Using a screwdriver, remove the 2nd coast and O/D hole snap ring from the transaxle case.

**46. REMOVE SUN GEAR REAR THRUST BEARING**


- (a) Remove the thrust needle roller bearing and thrust bearing race from the intermediate shaft.

**47. REMOVE FORWARD CLUTCH HUB SUB-ASSY**


- (a) Remove the forward clutch hub from the transaxle case.

**48. REMOVE FORWARD CLUTCH HUB THRUST NEEDLE ROLLER BEARING**


- (a) Remove the thrust needle roller bearing from the forward clutch hub.

**49. REMOVE FORWARD CLUTCH HOB THRUST BEARING RACE**

- (a) Remove the thrust bearing race from the planetary sun gear.


**50. REMOVE REAR PLANETARY SUN GEAR ASSY**

- (a) Remove the rear planetary sun gear assy from the trans-axle case.




51. REMOVE PLANETARY GEAR REAR THRUST NEEDLE ROLLER BEARING

- (a) Remove the thrust needle roller bearing from the rear planetary sun gear.




52. INSPECT 1 WAY CLUTCH NO.1

- (a) Hold the rear planetary sun gear and turn the 1 way clutch. The 1 way clutch should turn freely clockwise and should lock counterclockwise.




53. REMOVE 1 WAY CLUTCH NO.1

- (a) Remove the 2nd brake hub, 1 way clutch No. 1 and planetary gear thrust washer from the rear planetary sun gear.







- (b) Using a screwdriver, remove the one way clutch hole snap ring and remove the 1 way clutch No. 1 from the 2nd brake hub.




54. REMOVE 1 WAY CLUTCH RETAINER


- (a) Using a screwdriver, remove the 1 way clutch retainer from the 2nd brake hub.

**55. REMOVE PLANETARY CARRIER THRUST WASHER****56. REMOVE PLANETARY SUN GEAR SUB-ASSY****57. REMOVE FRONT PLANETARY FLANGE FRONT THRUST BEARING RACE****58. REMOVE SECOND BRAKE PISTON ASSY**

- (a) Using SST, a press and a screwdriver, remove the snap ring and brake piston assy.
 SST 09387-00070, 09950-70010 (09951-07100)


**59. REMOVE 2ND BRAKE PISTON RETURN SPRING SUB-ASSY**

- (a) Remove 2nd brake piston return spring from the trans-axle.




60. INSPECT 2ND BRAKE PISTON RETURN SPRING SUB-ASSY

- (a) Using vernier calipers, measure the free length of the spring together with spring seat.
Standard free length: 15.85 mm (0.6240 in.)



61. REMOVE 2ND BRAKE BRAKE DISC

- (a) Remove the 2 plates, 2 discs and flange.




62. INSPECT 2ND BRAKE BRAKE DISC



- (a) Check to see if the sliding surface of the disc, plate and flange are worn or burnt.
 If necessary, replace them.

NOTICE:


- If the lining of the disc is peeling off or discolored, or even if a part of the groove is defaced, replace all discs.
- Before assembling new discs, soak them in ATF for at least 15 minutes.





63. REMOVE BRAKE DRUM GASKET

**64. REMOVE OUTER RACE RETAINER****65. INSPECT 1 WAY CLUTCH NO.2**


- (a) Check that the planetary gear turns freely counterclockwise and locks clockwise.

**66. REMOVE 1 WAY CLUTCH NO.2**

- (a) Remove the No. 2 one-way clutch from the transaxle case.

**67. REMOVE PLANETARY GEAR ASSY****68. REMOVE 1ST & REVERSE BRAKE DISC**

- (a) Using SST, a press and a screwdriver, remove the snap ring, flange, 4 discs and 4 plates.
SST 09387-00070, 09950-70010 (09951-07100)




69. INSPECT 1ST & REVERSE BRAKE DISC


- (a) Check to see if the sliding surface of the disc, plate and flange are worn or burnt.
If necessary, replace them.

NOTICE:

- If the lining of the disc is peeling off or discolored, or even if a part of the printed number is defaced, replace all discs.
- Before assembling new discs, soak them in ATF for at least 15 minutes.




70. REMOVE 1ST & REVERSE BRAKE RETURN SPRING SUB-ASSY




71. INSPECT 1ST & REVERSE BRAKE RETURN SPRING SUB-ASSY


- (a) Using vernier calipers, measure the free length of the spring together with spring seat.
Standard free length: 21.71 mm (0.85472 in.)

**72. REMOVE COUNTER DRIVE GEAR NUT**


- (a) Using SST, lift the transaxle case.
SST 09223-15020, 09387-00060




- (b) Using SST and a hammer, unstack the counter drive gear nut.
SST 09930-00010




- (c) Remove the nut.
NOTICE:
Remove the nut without unstacking the planetary ring gear. If chisel or other tool is used to unstack the planetary ring gear, such impact may damage the bearing.

**73. REMOVE PLANETARY RING GEAR FLANGE**


- (a) Using SST and a press, remove the planetary ring gear.
SST 09950-60010 (09951-00420), 09950-70010 (09951-07100)

**74. REMOVE PLANETARY RING GEAR**

- (a) Using a screwdriver, remove the snap ring and remove the planetary ring gear from the planetary ring gear flange.

**75. REMOVE COUNTER DRIVE GEAR**


- (a) Install the 3 bolts to the counter drive gear.
Bolt (M6):
L = 40 - 80 mm
Pitch = 1.0 mm
- (b) Rotate 3 bolts in order and remove the counter drive gear and planetary ring gear.

**76. REMOVE 1ST & REVERSE BRAKE PISTON**


- (a) Apply compressed air (392 kPa, 4.0 kgf/cm², 57 psi) to the transaxle case to remove the 1st & reverse brake piston.

NOTICE:


- **Blowing off the air may cause the piston's jump-out. When removing the piston, hold it with your hand using a waste cloth.**
- **Take care not to splash ATF when air-blowing.**

**77. REMOVE 1ST & REVERSE BRAKE O-RING**


- (a) Remove the 2 O-rings from the 1st & reverse brake piston.

**78. REMOVE PARKING LOCK PAWL BRACKET**


- (a) Remove the 2 bolts and parking lock pawl bracket.

**79. REMOVE MANUAL VALVE LEVER SHAFT**


- (a) Using screwdriver, cut off the manual valve lever shaft spacer to remove.




- (b) Using a pin punch and hammer, drive out the pin.
 (c) Remove the manual valve lever shaft and manual valve lever.

**80. REMOVE PARKING LOCK ROD SUB-ASSY**


- (a) Remove the parking lock rod sub-assy from the manual valve lever.

**81. REMOVE MANUAL DETENT SPRING SUB-ASSY**


- (a) Remove the bolt and manual detente spring sub assy.

**82. REMOVE PARKING LOCK PAWL**

- (a) Remove the parking lock pawl shaft, torsion spring and parking lock pawl.


**83. REMOVE MANUAL VALVE LEVER SHAFT OIL SEAL**

- (a) Using a screwdriver the oil seal.


**84. REMOVE TRANSAXLE CASE NO.1 PLUG**

- (a) Remove 2 transaxle case No. 1 plugs.
- (b) Using a screwdriver, remove O-ring from the transaxle case No. 1 plug.

85. BEARING POSITION




Mark	Front Race Diameter Inside / Outside mm (in.)	Thrust Bearing Diameter Inside / Outside mm (in.)	Rear Race Diameter Inside / Outside mm (in.)
A	-	32.5 (1.280) / 48.5 (1.909) or 32.9 (1.295) / 48.5 (1.909)	-
B	-	17.8 (0.701) / 30.2 (1.189)	20.5 (0.807) / 32.6 (1.283)
C	19.3 (0.760) / 29.0 (1.142)	-	-
D	-	42.5 (1.673) / 57.5 (2.264)	-
E	34.95 (1.3670) / 45.50 (1.7913)	33.3 (1.311) / 46.5 (1.831)	-
F	19.3 (0.760) / 30.6 (1.205)	18.1 (0.713) / 29.6 (1.165)	18.1 (0.713) / 28.2 (1.110)
G	-	43.2 (1.701) / 62.0 (2.441)	-



86. ADJUST TAPERED POLLER BEARING PRELOAD

- (a) Install the transaxle housing and 16 bolts of the transaxle housing temporarily.
Tighten 8 or 9 bolts out of 16 bolts of the transaxle housing completely.

Torque: 29 N·m (300 kgf·cm, 22 ft·lbf)



- (b) Using SST and small torque wrench, measure the preload of the differential gear.

SST 09564-32011

Preload:

New bearing:

0.78 - 1.37 N·m (8.0 - 14.0 kgf·cm, 6.9 - 12.2 in·lbf)


Used bearing:

0.39 - 0.69 N·m (4.0 - 7.0 kgf·cm, 3.5 - 6.1 in·lbf)

If the preload is not within the specification, remove the differential from the transaxle case. Re-select the transaxle case side adjusting shim according to the following table.


Adjusting shim thickness: mm (in.)

Mark	Thickness	Mark	Thickness
A	1.80 (0.0709)	N	2.26 (0.0890)
B	1.85 (0.0728)	P	2.29 (0.0902)
C	1.90 (0.0748)	Q	2.32 (0.0913)
D	1.95 (0.768)	R	2.35 (0.0925)
E	2.00 (0.0787)	S	2.40 (0.0945)
F	2.05 (0.0807)	T	2.45 (0.0965)
G	2.08 (0.0819)	U	2.50 (0.0984)
H	2.11 (0.0831)	V	2.55 (0.1004)
J	2.14 (0.0843)	W	2.60 (0.1024)
K	2.17 (0.0854)	X	2.65 (0.1043)
L	2.20 (0.0866)	Y	2.70 (0.1063)
M	2.23 (0.0878)		

**87. INSTALL TRANSAXLE CASE NO.1 PLUG**

- (a) Install the 2 O-rings to the transaxle case No. 1 plug.
- (b) Install the 2 transaxle case No. 1 plugs to the transaxle case.

Torque: 7.4 N·m (75 kgf·cm, 65 in·lbf)


**88. INSTALL MANUAL VALVE LEVER SHAFT OIL SEAL**

- (a) Coat a new oil seal with ATF.
- (b) Using SST and a hammer, install the oil seal to the transaxle case.

Oil seal in depth:

A: 1 ± 0.25 mm (0.39 ± 0.0098 in.)


SST 09950-60010 (09951-00230), 09950-70010 (09951-07100)

**89. INSTALL PARKING LOCK PAWL**

- (a) Install the parking lock pawl shaft, torsion spring and parking lock pawl.


NOTICE:

Check that the edge of torsion spring fits into the groove securely.


**90. INSTALL MANUAL DETENT SPRING SUB-ASSY**

- (a) Install the manual detente spring with the bolt.

Torque: 9.8 N·m (100 kgf·cm, 7 ft·lbf)

**91. INSTALL PARKING LOCK ROD SUB-ASSY**


- (a) Install the parking lock rod sub-assy to the manual valve lever.

**92. INSTALL MANUAL VALVE LEVER SHAFT**


- (a) Install a new spacer to the manual valve lever.
- (b) Install the manual valve lever shaft and manual valve lever.
- (c) Using a pin punch and hammer, drive in a new pin.
- (d) Turn the spacer and lever shaft to align the small hole for locating the staking position in the spacer with the staking position mark on the lever shaft.

Using a pin punch, stake the spacer through the small hole.


Check that the spacer does not turn.

**93. INSTALL PARKING LOCK PAWL BRACKET**

- (a) Install the parking lock pawl bracket with the 2 bolts.
Torque: 7.4 N·m (75 kgf·cm, 65 in·lbf)

**94. INSTALL 1ST & REVERSE BRAKE O-RING**


- (a) Coat 2 new O-rings with ATF, install them to the 1st & reverse brake piston.

**95. INSTALL 1ST & REVERSE BRAKE PISTON**

- (a) Install the 1st & reverse brake piston to the transaxle case.


NOTICE:

Be careful not to damage the O-ring of the 1st & reverse brake piston.




96. INSTALL 1ST & REVERSE BRAKE RETURN SPRING SUB-ASSY

- (a) Install the return spring sub-assy to the transaxle case.



97. INSTALL 1ST & REVERSE BRAKE DISC

- (a) Install the 4 plates, 4 discs and flange.




- (b) Using SST, a press and a screwdriver, install the snap ring.

SST 09387-00070, 09950-70010 (09951-07100)

NOTICE:

Make sure that the snap ring is installed in the groove of the transaxle case correctly.




98. INSPECT PISTON STROKE OF 1ST & REVERSE BRAKE

- (a) Using a dial indicator and measuring terminal (SST), measure the 1st & reverse brake piston stroke while applying and releasing compressed air (392 - 785 kPa, 4 - 8 kgf/cm², 57 - 114 psi).

SST 09350-36010 (09350-06110)

Piston stroke 0.791 - 1.489 mm (0.031 - 0.057 in.)


If the piston stroke is non-standard, inspect the discs, plates and flange.

**99. INSTALL COUNTER DRIVE GEAR**


- (a) Using SST and a press, install the counter drive gear.
 SST 09223-15030, 09387-00060, 09950-60020
 (09951-00710), 09950-70010 (09951-07100)

NOTICE:


Be careful not to apply excessive force to the transaxle case.

**100. INSTALL PLANETARY RING GEAR**

- (a) Install the planetary ring gear to a new planetary ring gear flange and fix the snap ring using a screwdriver.

**101. INSTALL PLANETARY RING GEAR FLANGE**


- (a) Using SST and a press, install the planetary ring gear.
 SST 09223-15030, 09387-00060, 09950-60020
 (09951-00790), 09950-70010 (09951-07100)

**102. INSTALL COUNTER DRIVE GEAR NUT**


- (a) Using a small torque wrench, while turning to counter driver gear 100 turn per minute and measure the preload.

Preload:


0.05 – 0.35 N·m (0.5 – 3.6 kgf·cm, 0.43 – 3.12 in·lbf)




- (b) Using SST, lift the transaxle case.
SST 09223-15020, 09387-00060




- (c) Using a chisel and a hammer, stake the counter drive gear nut.

**103. INSTALL PLANETARY GEAR ASSY**


- (a) Install the planetary gear assy to the transaxle housing.

**104. INSTALL 1 WAY CLUTCH NO.2**



- (a) Install the 1 way clutch No. 2 to the transaxle.

**105. INSPECT 1 WAY CLUTCH NO.2**


- (a) Check that the planetary gear turns free counterclockwise and locks clockwise.

**106. INSTALL OUTER RACE RETAINER**

- (a) Install the anti-rattle clip in the place shown in the illustration (the space between the No. 2 one-way clutch outer race and transaxle case), push the anti-rattle clip in until you hear the "click".


**107. INSTALL BRAKE DRUM GASKET****108. INSTALL 2ND BRAKE BRAKE DISC**

- (a) Coat a flange, 2 discs and 2 plates with ATF, install it to the transaxle case.




109. INSTALL 2ND BRAKE PISTON RETURN SPRING SUB-ASSY

- (a) Coat the 2nd brake piston return spring with ATF, install it to the transaxle case.




110. INSTALL SECOND BRAKE PISTON ASSY

- (a) Coat the 2nd brake piston with ATF and install it as shown in the illustration on the left.




- (b) Using SST, a press and a screwdriver, remove the snap ring.
SST 09387-00070, 09950-70010 (09951-07100)




111. INSTALL FRONT PLANETARY FLANGE FRONT THRUST BEARING RACE

- (a) Coat the thrust bearing race with petroleum jelly and install it onto the front planetary sun gear.




112. INSTALL PLANETARY SUN GEAR SUB-ASSY

- (a) Install the planetary sun gear to the transaxle.




113. INSTALL 2ND COAST & OVERDRIVE BRAKE FLANGE HOLE SNAP RING

- (a) Using a screwdriver, install snap ring to the transaxle case.




114. INSTALL PLANETARY CARRIER THRUST WASHER

- (a) Install the washer to the planetary gear assy.




115. INSTALL 1 WAY CLUTCH RETAINER

- (a) Install the retainer to the 2nd brake hub.




116. INSTALL 1 WAY CLUTCH NO.1


- (a) Coat the 1 way clutch No. 1 with ATF, install it to the 2nd brake hub.
 (b) Using a screwdriver, install the snap ring to the 2nd brake hub.




- (c) Install the thrust washer to the 2nd brake hub.

**117. INSPECT 1 WAY CLUTCH NO.1**


- (a) Install the 1 way clutch and thrust washer to the rear planetary sun gear.
- (b) Hold the rear planetary sun gear and turn the 1 way clutch. The 1 way clutch should turn freely clockwise and should lock counterclockwise.

**118. INSTALL PLANETARY GEAR REAR THRUST NEEDLE ROLLER BEARING**


- (a) Coat the needle roller bearing with ATF, install it to the rear planetary gear.

**119. INSTALL REAR PLANETARY SUN GEAR ASSY**


- (a) Install the rear planetary sun gear assy to the transaxle case.

**120. INSTALL FORWARD CLUTCH HOB THRUST BEARING RACE**


- (a) Coat the thrust bearing race with petroleum jelly and install it onto the transaxle case.

**121. INSTALL FORWARD CLUTCH HUB THRUST NEEDLE ROLLER BEARING**


- (a) Coat the thrust needle roller bearing with petroleum jelly and install it onto the forward clutch hub.

**122. INSTALL FORWARD CLUTCH HUB SUB-ASSY**


- (a) Install the forward clutch hub to the transaxle case.

**123. INSTALL SUN GEAR REAR THRUST BEARING**


- (a) Install the thrust bearing and 2 braces to the intermediate shaft assy.

**124. INSTALL INTERMEDIATE SHAFT ASSY**


- (a) Install the intermediate shaft assy to the transaxle case.

**125. INSTALL 2ND COAST & OVERDRIVE BRAKE DISC**

- (a) Install the plate, 2 discs and 2 flanges to the transaxle case.

**126. INSPECT 2ND COAST & O/D BRAKE FLANGE, DISK AND PLATE**

- (a) As shown in the illustration, place a straight edge on the transaxle case and measure the distance between the 2nd coast & O/D brake flange and straight edge using vernier calipers. (Dimension A)



- (b) As shown in the illustration, place a straight edge on the O/D brake piston and measure the distance between the transaxle rear cover and straight edge using vernier calipers. (Dimension B)

Calculate the piston stroke value using the following formula. Select a flange which satisfies the piston stroke value and install it.


HINT:

Piston stroke = Dimension A - Dimension B

Piston stroke: 0.65 - 1.05 mm (0.0256 - 0.0413 in.)


Flange thickness: mm (in.)

Mark	Thickness	Piston stroke value
0	3.0 (0.118)	0.738 - 0.949 (0.02905 - 0.03736)
1	3.2 (0.126)	0.950 - 1.149 (0.03740 - 0.04524)
2	3.4 (0.134)	1.150 - 1.349 (0.04528 - 0.05311)
3	3.6 (0.142)	1.350 - 1.549 (0.05315 - 0.06098)
0	3.8 (0.150)	1.550 - 1.702 (0.06102 - 0.06701)




127. INSTALL TRANSAXLE CASE 2ND BRAKE GASKET

- (a) Install new 4 apply gaskets to the transaxle rear cover.



128. INSTALL FRONT CLUTCH DRUM THRUST NEEDLE ROLLER BEARING


- (a) Coat the thrust needle roller bearing with petroleum jelly and install it onto the forward & reverse clutch assembly.
 (b) Remove any packing material and be careful not to get oil on the contacting surfaces of the transaxle rear cover or transaxle case.

**129. INSTALL TRANSAXLE REAR COVER ASSY**

- (a) Apply FIPG to the transaxle rear cover.


FIPG:

Part No. 08826-00090, THREE BOND 1281 or equivalent





- (b) Install the transaxle rear cover to the transaxle case with the 9 bolts.


Torque: 25 N·m (250 kgf·cm, 18 ft·lbf)

**130. INSTALL TRANSMISSION CASE PLATE NO.1**


- (a) Install the transmission case plate No. 1 to the transaxle case with the bolt.

Torque: 9.8 N·m (100 kgf·cm, 7 ft·lbf)


**131. INSTALL GOVERNOR APPLY GASKET NO.2****132. INSTALL DIFFERENTIAL GEAR ASSEMBLY**

**133. INSTALL DIRECT CLUTCH HUB**

- (a) Install the direct clutch hub to the transaxle case.

**134. INSTALL PLANETARY GEAR FRONT THRUST NEEDLE ROLLER BEARING**


- (a) Install the thrust bearing race and thrust needle roller bearing to the transaxle case.

**135. INSTALL STATOR SHAFT THRUST NEEDLE ROLLER BEARING**


- (a) Install the thrust needle roller bearing to the transaxle case.

NOTICE:

Check the direction of the bearing.


**136. INSTALL INPUT SHAFT ASSY**

- (a) Install the input shaft assy to the transaxle case.


**137. INSTALL OIL PUMP ASSEMBLY**

- (a) Place the oil pump through the input shaft, and align the bolt holes of the oil pump with the transaxle case.
 (b) Install the 6 bolts.

Torque: 25 N·m (250 kgf·cm, 18 ft·lbf)

**138. INSPECT INPUT SHAFT ASSY**

- (a) Make sure that the input shaft turns smoothly.

**139. INSPECT INPUT SHAFT ENDPLAY**


- (a) Measure the end play in axial direction.

End play: 0.3 – 0.9 mm (0.012 – 0.035 in.)

If the end play is not as specified, select and replace the thrust needle roller bearing.

HINT:


There are 2 bearing in difference thickness, if necessary, select one of them.



140. INSTALL BREATHER PLUG NO.1 (ATM)**141. INSTALL TRANSAXLE HOUSING OIL SEAL**

- (a) Using SST and a hammer, drive in a new oil seal.

Oil seal in depth: 3.1 mm (0.122 in.)


SST 09517-12010, 09630-24014 (09620-24051)

**142. INSTALL DIFFERENTIAL GEAR LUBE APPLY TUBE**

**143. INSTALL TRANSMISSION LUBE APPLY TUBE****144. INSTALL TRANSAXLE APPLY TUBE CLAMP NO.1**


- (a) Install the transaxle apply tube clamp No. 1 to the transaxle housing with the bolt.

Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)

**145. INSTALL TRANSAXLE HOUSING OIL SEPARATOR**

- (a) Install the oil separator to the transaxle housing with the 3 bolts.

Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)

**146. INSTALL TRANSAXLE HOUSING**

- (a) Remove any packing material and be careful not to get oil on the contacting surfaces of the transaxle housing or transaxle case.

- (b) Apply FIPG to the transaxle housing.

FIPG:

Part No. 08826-00090, THREE BOND 1281 or equivalent

- (c) Install the transaxle housing to the transaxle case with the 16 bolts.


Torque: 29 N·m (300 kgf·cm, 22 ft·lbf)


HINT:

Apply seal packing or equivalent to the 3 bolts indicated by arrows.


Seal packing:

Part No. 08833-00070, THREE BOND 1324 or equivalent





**147. INSTALL TRANSAXLE CASE OIL SEAL**


- (a) Using SST and a hammer, drive in a new oil seal.
 SST 09316-60011 (09316-00011)
Oil seal in depth: 3.1 mm (0.122 in.)

**148. INSTALL TRANSAXLE HOUSING NO.2 PLUG**


- (a) Coat a new O-ring with ATF, install it to the screw plug.
 (b) Install the transaxle housing No. 2 plug to the transaxle case.
Torque: 7.4 N·m (75 kgf·cm, 65 in.·lbf)

**149. INSTALL B-1 ACCUMULATOR PISTON COMPRESSION SPRING****150. INSTALL PISTON B-1 ACCUMULATOR**


- (a) Install 2 O-rings to the B₁ accumulator piston.




- (b) Install the B₁ accumulator piston to the transaxle case.

**151. INSTALL C-1 ACCUMULATOR SPRING SUB-ASSY**


- (a) Install the C₁ accumulator spring to the C₁ accumulator piston with snap ring.

**152. INSTALL C-1 ACCUMULATOR PISTON**


- (a) Coat 2 new O-rings with ATF and install them to the C₁ accumulator piston.




- (b) Coat the piston with ATF and install it to the transaxle case.

**153. INSTALL C-2 ACCUMULATOR SPRING SUB-ASSY**


- (a) Install the C₂ accumulator spring to the C₂ accumulator piston with snap ring.

**154. INSTALL C-2 ACCUMULATOR PISTON**

- (a) Coat 2 new O-rings with ATF and install them to the C₂ accumulator piston.




- (b) Coat the piston with ATF and install it to the transaxle case.




155. INSTALL CHECK BALL BODY

- (a) Coat the spring and the check ball body with ATF and install them to the transaxle case.




156. INSTALL GOVERNOR APPLY GASKET NO.1

- (a) Coat the governor apply gasket No. 1 with ATF and install it to the transaxle case.




157. INSTALL TRANSMISSION WIRE

- (a) Coat a new O-ring with ATF and install it to the transmission wire.
 (b) Pierce the transmission wire to the transaxle.




- (c) Install the transmission wire and bolt.
Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)



158. INSTALL TRANSMISSION VALVE BODY ASSY

- (a) Connect the connecting rod to the manual valve lever, install the transmission valve body.




- (b) Torque the 14 bolts at the same torque each.
Torque: 11 N·m (110 kgf·cm, 8 ft·lbf)

NOTICE:


When installing the valve body to the transaxle case. do not hold the solenoids.

Bolt length:

- Bolt A: 20 mm (0.79 in.)**
- Bolt B: 28 mm (1.10 in.)**
- Bolt C: 49 mm (1.93 in.)**
- Bolt D: 36 mm (1.42 in.)**
- Bolt E: 40 mm (1.57 in.)**




- (c) Install the oil temperature sensor and solenoid connectors.




159. INSTALL VALVE BODY OIL STRAINER ASSY

- (a) Install a new gasket to the oil strainer.




- (b) Install the oil strainer to the transaxle assy with 3 bolts.
Torque: 9.8 N·m (100 kgf·cm, 7 ft·lbf)




160. INSTALL AUTOMATIC TRANSAXLE OIL PAN SUB-ASSY

- (a) Install 2 oil cleaner magnets to the 2 positions shown in the illustration on the left.




- (b) Install a new gasket and oil pan with 18 bolts.
Torque: 7.0 N·m (70 kgf·cm, 61 in·lbf)




161. INSTALL OIL COOLER TUBE UNION

- (a) Coat a new O-ring with ATF and install it to the oil cooler tube union.
Torque: 25 N·m (250 kgf·cm, 18 ft·lbf)




162. INSTALL BREATHER PLUG HOSE

- (a) Install the breather plug hose to the breather plug with clamp.


**163. INSTALL TRANSMISSION REVOLUTION SENSOR**

- (a) Coat a new O-ring with ATF and install it to the transmission revolution sensor.
- (b) Install the transmission revolution sensor to the transaxle with bolt.

Torque: 5.4 N·m (55 kgf·cm, 48 in.·lbf)

**164. INSTALL NEUTRAL START SWITCH ASSY**


- (a) Temporarily fasten the neutral start switch with 2 bolts.




- (b) Install the nut stopper and nut.

Torque: 6.9 N·m (70 kgf·cm, 61 in.·lbf)

- (c) Temporarily install the control shaft lever.




- (d) Turn the control shaft lever counterclockwise until it stops, then turn it clockwise 2 notches.




- (e) Align the groove with neutral basic line, tighten the 2 bolts.

Torque: 5.4 N·m (55 kgf·cm, 48 in.·lbf)



- (f) Using a screwdriver, stake the nut with the lock washer.



165. INSTALL TRANSMISSION CONTROL SHAFT LEVER

- (a) Install the control lever, washer and nut.
Torque: 12 N·m (120 kgf·cm, 9 ft·lbf)

166. INSTALL SPEEDOMETER DRIVEN (ATM) GEAR SUB-ASSY

167. INSTALL SPEEDOMETER (ATM) SENSOR